

Note: If phone players support for Bluetooth mobile phone format can be directly operated on the panel, without opening the phone player interface.

Bluetooth Mp3 adaptation:

- 1. Some phones do not support fade function, it will beep pop when play/pause and change songs
- 2. Bluetooth disconnect is Non-real-time detect, turn off Bluetooth for a while that the phone will disconnect.
- Some phone can paired but not connected, because the phone software need to detected.
- 4. Some domestic mobile phone Bluetooth signal is weak, receive signals form 5-7 Meter.

6. AUX:

Press



" to select AUX status ,as right::



7、 Volume adjustment: The volume can be adjusted by long press (\triangle) or (∇), and the screen will display volume DB number accordingly . Short press (\triangle) or (∇) to select MP3/BT tracks or FM channel.

Note: This system is 2+1 mega bass special audio processing.strong sound effect.it is recommended maximum configuration (2 + 1 channel) installation, in order to achieve the best sound when matching.

BATHTUB WITH MASSAGE JET USER MANUAL

- Please read this manual carefully before you using .
- Please save this manual carefully.

1.Features:

Using luxurious blue mini dynamic LCD, every function has matching English annotation in order to operate it more easier.

- (1). Automatic testing water level by microcomputer.
- (2) Surfing function.
- (3) Bubble bath massage function.
- (4), hypersensitized FM radio system: 20 channel memories, electronic volume adjustment, digital frequency modulation, automatically scanning
- (5), Ozone sterilization function (Configuration Options)
- (6) CD input function.
- (7). Underwater light.
- (8). Almighty remote controller
- (9) Touch Ttechnology function.
- (10), External thermostat function (Configuration Options)
- (11) USB connector Mp3 function
- (12)Phone bluetooth Mp3 player.

2. Specifications:


- (1) Power supply: AC220V \pm 10% 50/60Hz
- (2)、Pump load: AC220V ≤ 1500W
- (3). Bubble bath pump load: AC220V ≤750W
- (4), Dielectric strength: 1500V 1min
- (5), Leak current: <0.25mA
- (6)、Waterproof grade: IPX4
- (7). Ozone load: DC12V ≤ 10W(Configuration Options)
- (8), Lighting load: DC12V 10W
- (9). Music power: \leq 10 W
- (10), Frequency range: FM 88-108MHz
- (11), S/N radio: >45dB
- (12), Heater power: AC220V≤ 1500W(Configuration Options)

4, MP3 function:

Press "To select Mp3 atatus, as right:



(1) Play:select Mp3 position. inset USB with Mp3 tracks, the system play the track auto and display track time.



(2) , track up (next track): press " \triangle " or " ∇ " to select upward_track or next track.





5. connect with phone Bluetooth:

press to select position of bluetooth, display show"BT" and flash (search bluetooth sign)) then system search bluetooth and pairing. stop flash "BT" when pairing successful .at the first time need to pairing bluetooth, opearting as follow:

Open bluetooth setting of phone \longrightarrow open bluetooth \longrightarrow search equipment \longrightarrow pairing success

speaker broadcast a piece of music, display show **57** sign and stop flash(pairing finish) as follow:



At bluetooth mode play mobile phone's music: open mobile phone music player can operating as follow: play/pause:press \bigcirc to play or pause. Track selection:press \triangle or \bigvee to upward track or downward track.


2. Audio frequency function:




3 Radio function:


- (1) Pull out the radio antenna and place in "Y" form .When turn on radio function , the screen will appear radio frequency and the volume will rise from -0- to -15- DB with slight sound for loudspeaker.
- (2) Searching channel: pressing () again turn to tuned state ," will flicker at the same time . You can press (\triangle) or (∇) for upward or downward to select broadcasting station . Short pressing is for manual selection . Long press (more than 2 seconds) the frequency will move upward or downward automatically until the broadcasting station is received .
- (3) Memory: After selecting the broadcasting station, press (to display show" MEM "and "CH01" and store to this number. Then when store the broadcasting station next time, the store number will increase by degrees automatically. The store number is between (Ch01 to CH 20)..
- (4) Automatic selection: press (TUN), the screen will display "TUN", and press (TUN) at the same time the frequency will move upward or downward automatically and the effective channels will be saved, until finish the searching or the memory is full.
- (5) Pick up the memory: press (\triangle) or (∇) for selection of the position of desired station .the screen will display the number "C H 0 1 C H20" thus you can hear the sounds .

3. Circuit diagram



4. Panel description:






6. Operating instruction:

1. Surfing part:

(1)Power on/off: insert the plug, press (b) to switch on the power. You can perform setting and operation of various function according to the requirement of users. The system can be directly switch off by pressing (b).



Automatic keylock: If t no keyboard operation within two minutes, the system will automatically enter locked state. show \bigcap , press \bigcap to unlock.


Press "SET" to select the pump icon ,as shown to the right:



Notice: The water pump is limited by water level, it only be launched under the condition of water level. If short of water, the "the will flicker, water pump can not start. The pump will be turned off every time it worked 60 minutes.

(3) heating function (Configuration Options):





Notice: only under the surfing function on ,the heating function can be launched ,and control by the preset temperature .

Only under the radio/AUX function off ,the preset temperature can be changed by pressing (\triangle) or (∇) within 20°C--45°C (default 38°C). When the water temperature reach to the preset temperature ,it will turn into constant temperature .

(4) Bubble bath function:

Press "SET" to select the bubble bath icon ,as shown to the right:



О3

Notice: It will be turned off automatically every 60minutes.

(5) Lamp function:

Press "SET" to select the lamp icon ,as shown to the right:



(6) Ozone function:

Press " select the ozone icon , as shown to the right:



Notice: the work timing is 15 minutes.